

STRUBE INC.

**CAGE 54034**

**Aircraft Instrument Electromechanical Manufacturing**

**FAA Repair Station OX1R390K**

**Surplus Aircraft Instruments**

**An ISO-9001:2000 Corporation**

**629 W. Market St. Marietta PA 17547**


**Tel. 717-426-1906 Fax. 717-653-6461 [www.strubeinc.net](http://www.strubeinc.net)**

## *Repair & Overhaul Capabilities*



***Strube, Inc., Located in Marietta PA is privately held, ISO-9001:2000 registered corporation serving a worldwide base of U.S. Department of Defense, FAA, and commercial customers. In business since 1958, our product line includes:***

- ***Instrument repair & overhaul***
- ***Electro-mechanical Assembly/Cable Assy/Wire Harness***
  - ***Build to Print***
  - ***In house Design & Rapid Prototype***
- ***High Volume Production***
- ***Sales of surplus & specialty military and commercial instruments and other items***



***Need Repair/Overhaul of  
an Instrument not listed***

**?**

***Most instruments listed within this  
Report are common to our service  
Dept. Many others are within our  
scope.***

***Please call Strube @ 717-426-1906***

<b>Part Number</b>	<b>Description</b>	<b>Manufacturer</b>
5100		
6300	Dual Autosyn Indicator	Eclipse-Pioneer
6800		
6801		
45716	Engine Pressure Ratio Indicator	Airesearch
102379	Remote Attitude Indicator	Astronautics
112790	Attitude Indicator,ARU-39/A	Astronautics
135070	Flight Attitude Indicator	Astronautics
157800	Temperature Indicator, Thermocouple	Weston
157801		
176391		
415540	Tachometer Indicator	Norden-Ketay
617908	Directional Gyro Control	Sperry
656519	Directional Gyro Control	Sperry
669339	Directional Gyro Control	Sperry
673447	Directional Gyro Control	Sperry
1510340	Universal Attitude Indicator Test Set	Sperry
1777213	Gyrosyn Compass Indicator	Honeywell
1777214	Gyrosyn Compass Indicator	Honeywell
1778686	Gyrosyn Compass Indicator	Honeywell
1782755	Gyrosyn Compass Indicator	Honeywell
1782993	Gyrosyn Compass Indicator	Honeywell
1784389	Gyrosyn Compass Indicator	Honeywell
4006454	Liquid Quantity Transmitter	Simmonds/BFGoodrich
4006534	Liquid Quantity Transmitter	Simmonds/BFGoodrich
8200000	Pressure Switch	Electro National Corp.
010-002-001	Fuel Quantity Tank Unit	Gull
010-002-002	Fuel Quantity Tank Unit	Gull
010-002-003	Fuel Quantity Tank Unit	Gull
010-002-004	Fuel Quantity Tank Unit	Gull
010-002-005	Fuel Quantity Tank Unit	Gull
010-002-006	Fuel Quantity Tank Unit	Gull
010-002-007	Fuel Quantity Tank Unit	Gull
010-002-008	Fuel Quantity Tank Unit	Gull
010-002-009	Fuel Quantity Tank Unit	Gull

010-002-010	Fuel Quantity Tank Unit	Gull
010-002-011	Fuel Quantity Tank Unit	Gull
015-001-003	Hydraulic Reservoir Transmitter	Gull/Parker-Hannifin
015-001-004		
020-001-002	Fuel Quantity Tank Unit	Gull
020-001-003	Fuel Quantity Tank Unit	Gull
020-001-004	Fuel Quantity Tank Unit	Gull
020-001-005	Fuel Quantity Tank Unit	Gull
020-016-001	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-002	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-003	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-004	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-005	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-006	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-007	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-008	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-009	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-010	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-011	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-012	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-013	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-014	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-015	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-016	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-017	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-018	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-019	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-020	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-021	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-022	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-023	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-024	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-030	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-031	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-033	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-034	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-035M	Fuel Quantity Tank Unit	Gull/Parker-Hannifin
020-016-036M	Fuel Quantity Tank Unit	Gull/Parker-Hannifin



020-061-001	Fuel Quantity Tank Unit	Gull
020-061-002	Fuel Quantity Tank Unit	Gull
020-061-003	Fuel Quantity Tank Unit	Gull
020-061-004	Fuel Quantity Tank Unit	Gull
020-061-005	Fuel Quantity Tank Unit	Gull
020-061-006	Fuel Quantity Tank Unit	Gull
020-061-007	Fuel Quantity Tank Unit	Gull
020-061-008	Fuel Quantity Tank Unit	Gull
020-061-009	Fuel Quantity Tank Unit	Gull
020-061-010	Fuel Quantity Tank Unit	Gull
020-061-011	Fuel Quantity Tank Unit	Gull
020-061-012	Fuel Quantity Tank Unit	Gull
020-061-013	Fuel Quantity Tank Unit	Gull
020-061-014	Fuel Quantity Tank Unit	Gull
020-061-015	Fuel Quantity Tank Unit	Gull
020-061-016	Fuel Quantity Tank Unit	Gull
020-061-017	Fuel Quantity Tank Unit	Gull
020-061-018	Fuel Quantity Tank Unit	Gull
020-061-019	Fuel Quantity Tank Unit	Gull
020-061-020	Fuel Quantity Tank Unit	Gull
020-061-021	Fuel Quantity Tank Unit	Gull
020-061-022	Fuel Quantity Tank Unit	Gull
020-061-023	Fuel Quantity Tank Unit	Gull
020-061-024	Fuel Quantity Tank Unit	Gull
020-061-025	Fuel Quantity Tank Unit	Gull
10-3269-10		Switches
10-60552-41	Gage Pressure Switch	Boeing
10-60552-42	Gage Pressure Switch	Boeing
10-60927-3	Pressure Switch	Boeing
1160-8	Liquid Oxygen Quantity Indicator	Penn Airborne
116595-01	Attitude Indicator	Lear Seigler
118930-02-01	Attitude Indicator	Lear Seigler
1214BX-8-05	Sensitive Max. Airspeed Indicator	Kollsman
1214CX-8-05	Sensitive Max. Airspeed Indicator	Kollsman
1214DX-8-05	Sensitive Max. Airspeed Indicator	Kollsman
1214X-8-05	Sensitive Max. Airspeed Indicator	Kollsman
122141-001	Hermetically Sealed Switches	SAIA-Burgess
123550-01	Attitude Indicator Amplifier	Lear Siegler

124215-01		
128941-001	(Ledex)	(Ledex)
131080-01	Remote Attitude Indicator	Lear Siegler
131081-01		
136000-01-01	Attitude Director Indicator	Lear Siegler
136000-01-02	Attitude Director Indicator	Lear Siegler
136000-01-03	Attitude Director Indicator	Lear Siegler
136601-01-03	Attitude Indicator	Lear Seigler
136910-01-01	Attitude Director Indicator	Lear Siegler
138094-01-01	Attitude Indicator	Lear Seigler
138094-01-02	Attitude Indicator	Lear Seigler
139602-01-01	Attitude Director Indicator	Lear Siegler (LSI)
144700-01-01	Attitude Indicator	Lear Siegler
145201-454		
152B2	Indicators, Temperature	Lewis Engineering
152B3		
152B4		
152B5		
152BCL4	Thermocouple Thermometer	Lewis Engineering
152BCL4A	Thermocouple Thermometer	Lewis Engineering
152BCL4B	Thermocouple Thermometer	Lewis Engineering
152BCL4C	Thermocouple Thermometer	Lewis Engineering
152BCL4D	Thermocouple Thermometer	Lewis Engineering
152BCL4F	Thermocouple Thermometer	Lewis Engineering
152BCL4G	Thermocouple Thermometer	Lewis Engineering
152BCL4G2	Thermocouple Thermometer	Lewis Engineering
152BCL4H	Thermocouple Thermometer	Lewis Engineering
152BCL4J	Thermocouple Thermometer	Lewis Engineering
152BCL4J2	Thermocouple Thermometer	Lewis Engineering
152BCL4J3	Thermocouple Thermometer	Lewis Engineering
152BCL4P	Thermocouple Thermometer	Lewis Engineering
152BCL4R	Thermocouple Thermometer	Lewis Engineering
152BCL4S	Thermocouple Thermometer	Lewis Engineering
152BCL4W	Thermocouple Thermometer	Lewis Engineering
152BCL4W2	Thermocouple Thermometer	Lewis Engineering
152BL702	Thermocouple Temp. Indicator	Horizon Aerospace
152BL702A	Thermocouple Temp. Indicator	Horizon Aerospace
152BL702C	Thermocouple Temp. Indicator	Horizon Aerospace

152BL702D	Thermocouple Temp. Indicator	Horizon Aerospace
152BL702E	Thermocouple Temp. Indicator	Horizon Aerospace
152BL703	Thermocouple Temp. Indicator	Horizon Aerospace
152BL704	Thermocouple Temp. Indicator	Horizon Aerospace
152BL706	Thermocouple Temp. Indicator	Horizon Aerospace
152BL708	Thermocouple Temp. Indicator	Horizon Aerospace
152BL708A	Thermocouple Temp. Indicator	Horizon Aerospace
152BL708B	Thermocouple Temp. Indicator	Horizon Aerospace
152BL708H	Thermocouple Temp. Indicator	Horizon Aerospace
152BL709	Thermocouple Temp. Indicator	Horizon Aerospace
152BL709A	Thermocouple Temp. Indicator	Horizon Aerospace
152BL722	Thermocouple Temp. Indicator	Horizon Aerospace
152BL801	Thermocouple Temp. Indicator	Horizon Aerospace
152BL801A	Thermocouple Temp. Indicator	Horizon Aerospace
152BL801B	Thermocouple Temp. Indicator	Horizon Aerospace
152BL801C	Thermocouple Temp. Indicator	Horizon Aerospace
152BL801D	Thermocouple Temp. Indicator	Horizon Aerospace
152BL801E	Thermocouple Temp. Indicator	Horizon Aerospace
152BL802A	Thermocouple Temp. Indicator	Horizon Aerospace
152BL802B	Thermocouple Temp. Indicator	Horizon Aerospace
152BL802C	Thermocouple Temp. Indicator	Horizon Aerospace
152BL802D	Thermocouple Temp. Indicator	Horizon Aerospace
152BL803	Thermocouple Temp. Indicator	Horizon Aerospace
152BL803A	Thermocouple Temp. Indicator	Horizon Aerospace
152BL803B	Thermocouple Temp. Indicator	Horizon Aerospace
152BL803C	Thermocouple Temp. Indicator	Horizon Aerospace
156578-01-01		
161B101	Electrical Resistance Thermometer	Lewis Engineering
161BL302	Electrical Resistance Thermometer	Lewis Engineering
161BL501	Electrical Resistance Thermometer	Lewis Engineering
161C3	Electrical Thermometer	Lewis Engineering
161C9	Electrical Thermometer	Lewis Engineering
162B101	Electrical Resistance Thermometer	Lewis Engineering
162B4		
162BCL10	Electrical Thermometer	Lewis Engineering
162BCL10	Electrical Resistance Thermometer	Lewis Engineering
162BCL10F	Electrical Resistance Thermometer	Lewis Engineering
162BCL10W	Electrical Resistance Thermometer	Lewis Engineering

162BCL10WC	Electrical Resistance Thermometer	Lewis Engineering
162BCL11	Electrical Thermometer	Lewis Engineering
162BCL11	Electrical Resistance Thermometer	Lewis Engineering
162BCL11A	Electrical Resistance Thermometer	Lewis Engineering
162BCL11W	Electrical Resistance Thermometer	Lewis Engineering
162BCL12	Electrical Thermometer	Lewis Engineering
162BCL12	Electrical Resistance Thermometer	Lewis Engineering
162BCL12W	Electrical Resistance Thermometer	Lewis Engineering
162BCL15	Electrical Thermometer	Lewis Engineering
162BCL15	Electrical Resistance Thermometer	Lewis Engineering
162BCL15W	Electrical Resistance Thermometer	Lewis Engineering
162BCL16	Electrical Thermometer	Lewis Engineering
162BCL16	Electrical Resistance Thermometer	Lewis Engineering
162BCL16	Electrical Resistance Thermometer	Lewis Engineering
162BCL16A	Electrical Resistance Thermometer	Lewis Engineering
162BCL16B	Electrical Resistance Thermometer	Lewis Engineering
162BCL16W	Electrical Resistance Thermometer	Lewis Engineering
162BCL16WC	Electrical Resistance Thermometer	Lewis Engineering
162BCL17	Electrical Thermometer	Lewis Engineering
162BCL17	Electrical Resistance Thermometer	Lewis Engineering
162BCL17	Electrical Resistance Thermometer	Lewis Engineering
162BCL17W	Electrical Thermometer	Lewis Engineering
162BCL17W	Electrical Resistance Thermometer	Lewis Engineering
162BCL19	Electrical Resistance Thermometer	Lewis Engineering
162BCL20	Electrical Resistance Thermometer	Lewis Engineering
162BCL20A	Electrical Resistance Thermometer	Lewis Engineering
162BCL20B	Electrical Resistance Thermometer	Lewis Engineering
162BCL20C	Electrical Resistance Thermometer	Lewis Engineering
162BCL21	Electrical Resistance Thermometer	Lewis Engineering
162BCL22	Electrical Resistance Thermometer	Lewis Engineering
162BCL23	Electrical Resistance Thermometer	Lewis Engineering
162BCL27	Electrical Resistance Thermometer	Lewis Engineering
162BCL33	Electrical Resistance Thermometer	Lewis Engineering
162BCL33W	Electrical Resistance Thermometer	Lewis Engineering
162BL403C	Electrical Resistance Thermometer	Lewis Engineering
162BL501	Electrical Resistance Thermometer	Lewis Engineering
162BL502	Electrical Resistance Thermometer	Lewis Engineering
162BL503	Electrical Resistance Thermometer	Lewis Engineering

162BL504	Electrical Resistance Thermometer	Lewis Engineering
162BL505	Electrical Resistance Thermometer	Lewis Engineering
162BL602	Electrical Resistance Thermometer	Lewis Engineering
162BL701	Electrical Resistance Thermometer	Lewis Engineering
162BL701A	Electrical Resistance Thermometer	Lewis Engineering
162BL702	Electrical Resistance Thermometer	Lewis Engineering
162BL703	Electrical Resistance Thermometer	Lewis Engineering
162BL704	Electrical Resistance Thermometer	Lewis Engineering
162BL704A	Electrical Resistance Thermometer	Lewis Engineering
162BL704C	Electrical Resistance Thermometer	Lewis Engineering
162BL704D	Electrical Resistance Thermometer	Lewis Engineering
162BL704F	Electrical Resistance Thermometer	Lewis Engineering
162BL704H	Electrical Resistance Thermometer	Lewis Engineering
162BL704K	Electrical Resistance Thermometer	Lewis Engineering
162BL704L	Electrical Resistance Thermometer	Lewis Engineering
162BL704N	Electrical Resistance Thermometer	Lewis Engineering
162BL801	Electrical Resistance Thermometer	Lewis Engineering
162BL802	Electrical Resistance Thermometer	Lewis Engineering
162BL802A	Electrical Resistance Thermometer	Lewis Engineering
162BL803	Electrical Resistance Thermometer	Lewis Engineering
162BL803A	Electrical Resistance Thermometer	Lewis Engineering
162BL804A	Electrical Resistance Thermometer	Lewis Engineering
162BL901	Electrical Resistance Thermometer	Lewis Engineering
162BL902	Electrical Resistance Thermometer	Lewis Engineering
162BL903	Electrical Resistance Thermometer	Lewis Engineering
162BL906	Electrical Resistance Thermometer	Lewis Engineering
162BL907	Electrical Resistance Thermometer	Lewis Engineering
162C16	Electrical Thermometer	Lewis Engineering
162C17	Electrical Thermometer	Lewis Engineering
162C18	Electrical Thermometer	Lewis Engineering
162C20B	Electrical Thermometer	Lewis Engineering
162C21	Electrical Thermometer	Lewis Engineering
162C22	Electrical Thermometer	Lewis Engineering
162C23	Electrical Thermometer	Lewis Engineering
162C25	Electrical Thermometer	Lewis Engineering
162C27	Electrical Thermometer	Lewis Engineering
162C28	Electrical Thermometer	Lewis Engineering
162C30	Electrical Thermometer	Lewis Engineering

162C31	Electrical Thermometer	Lewis Engineering
162C7	Electrical Thermometer	Lewis Engineering
162C7A	Electrical Thermometer	Lewis Engineering
162C9	Electrical Thermometer	Lewis Engineering
162CL81	Electrical Resistance Thermometer	Lewis Engineering
162CL81W	Electrical Resistance Thermometer	Lewis Engineering
162CL82W	Electrical Resistance Thermometer	Lewis Engineering
162L2	Temp. Indicator	Lewis Engineering
162L2	Temperature Indicator	Lewis Engineering
162L3	Temp. Indicator	Lewis Engineering
162L3	Temperature Indicator	Lewis Engineering
162L3A	Temp. Indicator	Lewis Engineering
162L3A	Temperature Indicator	Lewis Engineering
162L4	Temp. Indicator	Lewis Engineering
162L4	Temperature Indicator	Lewis Engineering
162L4B	Temp. Indicator	Lewis Engineering
162L4B	Temperature Indicator	Lewis Engineering
162L4C	Temp. Indicator	Lewis Engineering
162L4C	Temperature Indicator	Lewis Engineering
163B2	Temperature Indicator	Lewis Engineering
164-1	Liquid Oxygen Quantity Indicator	Penn Airborne
172934-001		
172935-001		
172936-001		
172937-001		
172938-001		
172962-001		
175095-001		
175096-001		
18-1105	Hydraulic Pressure Indicator	Courter
18-1700	Pressure Indicator	Bendix
18-1701		
18-1702		
18-2099		
187408-001		
1G309	Pressure Switch	Custom Control Sensors
1G386	Pressure Switch	Custom Control

200-002-001	Fuel Quantity Master Indicator	Sensors Gull Airborne
200-002-002		
20041-0000-03	Liquid Quantity Transmitter	Simmonds(BFG)
20043-0000-01	Liquid Quantity Transmitter	Simmonds/BFGoodrich
20044-0000-01	Liquid Quantity Transmitter	Simmonds/BFGoodrich
20138-1000-0101	Liquid Quantity Transmitter	Simmonds/BFGoodrich
20138-1000-0201	Liquid Quantity Transmitter	Simmonds/BFGoodrich
20139-1000-0101	Liquid Quantity Transmitter	Simmonds/BFGoodrich
20139-1000-0201	Liquid Quantity Transmitter	Simmonds/BFGoodrich
20140-1000-0101	Liquid Quantity Transmitter	Simmonds/BFGoodrich
20140-1000-0201	Liquid Quantity Transmitter	Simmonds/BFGoodrich
212-070-160-1	Dual Torque Indicator	Edison
218-100	Oil Pressure Transmitter	Edison
218-100A		
218-50A		
22A524	Tachometer Generator	Globe Industries
238D1024-509	Differential Pressure Switch	Rohr
290D8042-503	Overpressure Indicator	Rohr
2CM11BAA4	Tachometer Generator	General Electric
2CM11BAA4	Tachometer Generator	General Electric
2CM11BAA5		
2CM11BAA5		
2CM5ABW	Electric Tachometer	General Electric
2CM5ACE	Electric Tachometer	General Electric
2CM5ACZ	Electric Tachometer	General Electric
2CM5ADR	Electric Tachometer	General Electric
2CM5AEN	Electric Tachometer	General Electric
2CM5BAL	Electric Tachometer	General Electric
2CM5BAM	Electric Tachometer	General Electric
2CM7AAA	Electric Tachometer	General Electric
2CM7AAN	Electric Tachometer	General Electric
2CM9AAA	Electric Tachometer	General Electric
2CM9AAA6	Electric Tachometer	General Electric
2CM9AAA6	Tachometer Generator	Ametek
2CM9AAB	Electric Tachometer	General Electric
2CM9AAC	Electric Tachometer	General Electric
2CM9AAC6	Electric Tachometer	General Electric

2CM9AAC6	Tachometer Generator	Ametek
2CM9AAF	Electric Tachometer	General Electric
2CM9AAH4	Tachometer Generator	Ametek
2CM9AAH4	Tachometer Generator	General Electric
2CM9AAV6	Tachometer Generator	Ametek
2CM9AAZ6	Tachometer Generator	Ametek
2CM9ABE6	Tachometer Generator	Ametek
2CM9ABH7	Tachometer Generator	Ametek
2CM9ABK7	Tachometer Generator	Ametek
2CM9ABY7	Tachometer Generator	Ametek
2CM9ABZ7	Tachometer Generator	Ametek
2CM9ACE7	Tachometer Generator	Ametek
2CM9ACF8	Tachometer Generator	Ametek
2CM9ACH7	Tachometer Generator	Ametek
2CM9ADB9	Tachometer Generator	Ametek
2CM9ADE8	Tachometer Generator	Ametek
2CM9ADT6	Tachometer Generator	Ametek
30-0837 -1	Anti-collision Light, Strobe	Grimes
30-0837 -13	Anti-collision Light, Strobe	Grimes
30-0837 -15	Anti-collision Light, Strobe	Grimes
30-0837 -17	Anti-collision Light, Strobe	Grimes
30-0837 -19	Anti-collision Light, Strobe	Grimes
30-0837 -21	Anti-collision Light, Strobe	Grimes
30-0837 -23	Anti-collision Light, Strobe	Grimes
30-0837 -25	Anti-collision Light, Strobe	Grimes
30-0837 -27	Anti-collision Light, Strobe	Grimes
30-0837 -29	Anti-collision Light, Strobe	Grimes
30-0837 -3	Anti-collision Light, Strobe	Grimes
30-0837 -31	Anti-collision Light, Strobe	Grimes
30-0837 -33	Anti-collision Light, Strobe	Grimes
30-0837 -35	Anti-collision Light, Strobe	Grimes
30-0837 -37	Anti-collision Light, Strobe	Grimes
30-0837 -39	Anti-collision Light, Strobe	Grimes
30-0837 -41	Anti-collision Light, Strobe	Grimes
30-0837 -43	Anti-collision Light, Strobe	Grimes
30-0837 -45	Anti-collision Light, Strobe	Grimes
30-0837 -47	Anti-collision Light, Strobe	Grimes
30-0837 -5	Anti-collision Light, Strobe	Grimes

30-0837 -7	Anti-collision Light, Strobe	Grimes
30-0837 -9	Anti-collision Light, Strobe	Grimes
30-0837-11	Anti-collision Light, Strobe	Grimes
30-0909-1	Tail Position Light	Grimes
30-0909-101	Tail Position Light	Grimes
30-0909-103	Tail Position Light	Grimes
30-0909-107	Tail Position Light	Grimes
30-0909-201	Tail Position Light	Grimes
30-0909-203	Tail Position Light	Grimes
30-0909-207	Tail Position Light	Grimes
30-1033 -1	Anti-collision Light, Flashtube	Grimes
30-1033 -11	Anti-collision Light, Flashtube	Grimes
30-1033 -13	Anti-collision Light, Flashtube	Grimes
30-1033 -17	Anti-collision Light, Flashtube	Grimes
30-1033 -19	Anti-collision Light, Flashtube	Grimes
30-1033 -21	Anti-collision Light, Flashtube	Grimes
30-1033 -23	Anti-collision Light, Flashtube	Grimes
30-1033 -25	Anti-collision Light, Flashtube	Grimes
30-1033 -27	Anti-collision Light, Flashtube	Grimes
30-1033 -29	Anti-collision Light, Flashtube	Grimes
30-1033 -3	Anti-collision Light, Flashtube	Grimes
30-1033 -31	Anti-collision Light, Flashtube	Grimes
30-1033 -33	Anti-collision Light, Flashtube	Grimes
30-1033 -35	Anti-collision Light, Flashtube	Grimes
30-1033 -37	Anti-collision Light, Flashtube	Grimes
30-1033 -39	Anti-collision Light, Flashtube	Grimes
30-1033 -41	Anti-collision Light, Flashtube	Grimes
30-1033 -43	Anti-collision Light, Flashtube	Grimes
30-1033 -45	Anti-collision Light, Flashtube	Grimes
30-1033 -49	Anti-collision Light, Flashtube	Grimes
30-1033 -5	Anti-collision Light, Flashtube	Grimes
30-1033 -51	Anti-collision Light, Flashtube	Grimes
30-1033 -53	Anti-collision Light, Flashtube	Grimes
30-1033 -55	Anti-collision Light, Flashtube	Grimes
30-1033 -57	Anti-collision Light, Flashtube	Grimes
30-1033 -59	Anti-collision Light, Flashtube	Grimes
30-1033 -61	Anti-collision Light, Flashtube	Grimes
30-1033 -63	Anti-collision Light, Flashtube	Grimes

30-1033 -65	Anti-collision Light, Flashtube	Grimes
30-1033 -67	Anti-collision Light, Flashtube	Grimes
30-1033 -7	Anti-collision Light, Flashtube	Grimes
30-1033-15	Anti-collision Light, Flashtube	Grimes
318-100		
318-60		
32005-007	Tachometer Generator	A/C Appliances and
32005-008	Tachometer Generator	Equipment
32005-023	Tachometer Generator	
32005-025	Tachometer Generator	
32005-026	Tachometer Generator	
		Custom Control
32D37-1	Differential Pressure Switch	Sensors
34100-C1D-6-1C1	Electrical Tachometer Indicator	Bendix
34101-C1E-7-1C1	Electrical Tachometer Indicator	Bendix
34300-C1A-1-A1	Pressure Ratio Indicator	Bendix
36148-1AJ25A1	Radio Magnetic Compass Indicator	Allied Signal
36148-1AJ25A2	Radio Magnetic Compass Indicator	Allied Signal
36154-1AF25A1	Radio Magnetic Compass Indicator	Allied Signal
36154-1AF25B1	Radio Magnetic Compass Indicator	Allied Signal
36154-1AJ25A1	Radio Magnetic Compass Indicator	Allied Signal
36154-1AJ25B1	Radio Magnetic Compass Indicator	Allied Signal
36154-1AJ33B1	Radio Magnetic Compass Indicator	Allied Signal
36155-1AF25A1	Radio Magnetic Compass Indicator	Allied Signal
36155-1AF25A2	Radio Magnetic Compass Indicator	Allied Signal
36155-1AJ25A1	Radio Magnetic Compass Indicator	Allied Signal
36162-1AJ25A1	Radio Magnetic Compass Indicator	Allied Signal
391001-153	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-155	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-159	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-161	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-163	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-167	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-169	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-171	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-173	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-177	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-179	Liquid Quantity Transmitter	Simmonds/BFGoodrich

391001-181	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-183	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-185	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-187	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-189	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-191	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-193	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-343	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-344	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-345	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-346	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-347	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-348	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-349	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-350	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-351	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-352	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-353	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-354	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-355	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-356	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-357	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-358	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-359	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391001-360	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391041-009	Liquid Quantity Compensator	Simmonds/BFGoodrich
391041-020	Liquid Quantity Compensator	Simmonds/BFGoodrich
391041-021	Liquid Quantity Compensator	Simmonds/BFGoodrich
391041-022	Liquid Quantity Compensator	Simmonds/BFGoodrich
391041-024	Liquid Quantity Compensator	Simmonds/BFGoodrich
391041-025	Liquid Quantity Compensator	Simmonds/BFGoodrich
391041-05007	Liquid Quantity Compensator	Simmonds/BFGoodrich
391041-06008	Liquid Quantity Compensator	Simmonds/BFGoodrich
391046-01433	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-04128	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-04129	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-04130	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-04131	Liquid Quantity Transmitter	Simmonds/BFGoodrich



391046-181	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-182	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-183	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-184	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-250	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-251	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-252	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-253	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-254	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-282	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-283	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-284	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-285	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-286	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-287	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-299	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-300	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-477	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-478	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-479	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-480	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-481	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-482	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-483	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-484	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-485	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391046-486	Liquid Quantity Transmitter	Simmonds/BFGoodrich
391097-16001	Liquid Quantity Transmitter	Simmonds
391097-16002	Liquid Quantity Transmitter	Simmonds
391097-16003	Liquid Quantity Transmitter	Simmonds
391097-16004	Liquid Quantity Transmitter	Simmonds
391097-16005	Liquid Quantity Transmitter	Simmonds
391097-16006	Liquid Quantity Transmitter	Simmonds
391097-16007	Liquid Quantity Transmitter	Simmonds
391097-16008	Liquid Quantity Transmitter	Simmonds
391097-16009	Liquid Quantity Transmitter	Simmonds
391097-16010	Liquid Quantity Transmitter	Simmonds
391097-16011	Liquid Quantity Transmitter	Simmonds

391097-16012	Liquid Quantity Transmitter	Simmonds
391097-16013	Liquid Quantity Transmitter	Simmonds
391097-16014	Liquid Quantity Transmitter	Simmonds
391097-16015	Liquid Quantity Transmitter	Simmonds
391097-16016	Liquid Quantity Transmitter	Simmonds
391097-16017	Liquid Quantity Transmitter	Simmonds
393003-013	Fuel Quantity Indicator	Simmonds
393004-060	Fuel Quantity Indicator	Simmonds
393004-061		
393004-34750	Fuel Quantity Indicator	Simmonds
393007-07869	Fuel Quantity Indicator	Simmonds
393007-07870		
393008-035	Fuel Quantity Indicator	Simmonds
393008-036	Fuel Quantity Indicator	Simmonds
393008-037	Fuel Quantity Indicator	Simmonds
393008-040	Fuel Quantity Indicator	Simmonds
393008-042	Fuel Quantity Indicator	Simmonds
393008-046	Fuel Quantity Indicator	Simmonds
393008-047	Fuel Quantity Indicator	Simmonds
393008-056	Fuel Quantity Indicator	Simmonds
393008-064	Fuel Quantity Indicator	Simmonds
393008-074	Fuel Quantity Indicator	Simmonds
393008-077	Fuel Quantity Indicator	Simmonds
393008-078	Fuel Quantity Indicator	Simmonds
393008-082	Fuel Quantity Indicator	Simmonds
393080-117	Dual Total Fuel Indicator	Simmonds/BFGoodrich
393080-118	Dual Total Fuel Indicator	Simmonds/BFGoodrich
393080-121	Dual Total Fuel Indicator	Simmonds/BFGoodrich
394473-101	Variable Capacitor Trimmer Unit	Simmonds
394473-131		
40-0135-10	Wing Position Light	Grimes
40-0135-3	Wing Position Light	Grimes
40-0135-4	Wing Position Light	Grimes
40-0135-7	Wing Position Light	Grimes
40-0135-8	Wing Position Light	Grimes
40-0135-9	Wing Position Light	Grimes
41105-C5A-4-B3	Dual Tachometer Indicator	Bendix
41105-C5A-4-E3		

418-00041	Oil Pressure Transmitter	Armtec
418-00044		
418-00141		
418-01064	Torque Pressure Transmitter	Edison Custom Control
42D107A1	Differential Pressure Switch	Sensors
42D223	Differential Pressure switch	Custom Component
42D49C	Pressure Switch	Custom Component
45-0148-10	Landing Light, Retractable	Grimes
45-0148-3	Landing Light, Retractable	Grimes
45-0148-4	Landing Light, Retractable	Grimes
45-0148-7	Landing Light, Retractable	Grimes
45-0148-8	Landing Light, Retractable	Grimes
45-0148-9	Landing Light, Retractable	Grimes
45716-1		Custom Control
45D16	Switch, Gage Pressure	Sensors
45D16-1		
45D32	Differential Pressure Switch	Custom Control Sensors
45D34	Differential Pressure Switch	Custom Control Sensors
501-1230-01	Attitude Indicator	JET Electronics
53D13247		
610BL24B	Electrical Resistance Thermometer	Lewis Engineering
610BL29	Electrical Resistance Thermometer	Lewis Engineering
610BL3	Electrical Resistance Thermometer	Lewis Engineering
610BL3B	Electrical Resistance Thermometer	Lewis Engineering
610BL4	Electrical Resistance Thermometer	Lewis Engineering
610BL4B	Electrical Resistance Thermometer	Lewis Engineering
610BL4D	Electrical Resistance Thermometer	Lewis Engineering
610BL4E	Electrical Resistance Thermometer	Lewis Engineering
610BL4H	Electrical Resistance Thermometer	Lewis Engineering
610BL9	Electrical Resistance Thermometer	Lewis Engineering
622-0290-004		
622-0292-003	Horizontal Situation Indicator	Collins
64891-001-1	Position Indicator, Control Surface	Jaeger
64891-002-1	Position Indicator, Control Surface	Jaeger
64891-002-2	Position Indicator, Control Surface	Jaeger

64891-002-3	Position Indicator, Control Surface	Jaeger
64891-002-4	Position Indicator, Control Surface	Jaeger
653894-6BA	Directional Gyroscopic Indicator	Sperry
664-1	Liquid Oxygen Quantity Indicator	Penn Airborne
664-2	Liquid Oxygen Quantity Indicator	Penn Airborne
664-2HEA	Liquid Oxygen Quantity Indicator	Penn Airborne
7609-37-B5-2	Autosyn Gage Pressure Transmitter	Bendix
7609-37-D5-2		
7609-37-M5-2		
7612-17-B5-1	Pressure Transmitter Gage	Bendix Corporation
77-149-1	Oil Quantity Transmitter	Meggitt Electronics
779-1	Indicator, water gauging	Avtech
8AW59FAA1	Frequency Meter	General Electric
8AW59FAC1		
8AW60F1AA1	Frequency Meter	General Electric
8AW60F2AA1		
8AW60LFA1		
8AW61A1AA1		
8AW61A2AA1		
8AW61LAA1		
8AW61LAB1		
8AW61LAC2		
8AW61LAD2		
8AW61LAH1		
8AW61LVA1		
8AW61V1AA1	Ammeter and Voltmeter	General Electric
8D1274	Gage Pressure Switch	Custom Control Sensors
8D1494	Gage Pressure Switch	Custom Control Sensors
8DH81LWN2	Tachometer Indicator	Ametek
8DH81LXT2	Tachometer Indicator	Ametek
8DJ12GAV50	Position Indicator	General Electric
8DJ131LAB-1	Triple Tach Indicator	General Electric
8DJ13ABN	Electric Tachometer	General Electric
8DJ13AFN	Electric Tachometer	General Electric
8DJ13AFX	Electric Tachometer	General Electric
8DJ13AKD	Electric Tachometer	General Electric

8DJ19AAR	Electric Tachometer	General Electric
8DJ19AAS	Electric Tachometer	General Electric
8DJ19AAW	Electric Tachometer	General Electric
8DJ19AAX	Electric Tachometer	General Electric
8DJ19ABE	Electric Tachometer	General Electric
8DJ19ABF	Electric Tachometer	General Electric
8DJ19ACA	Electric Tachometer	General Electric
8DJ19ACB	Electric Tachometer	General Electric
8DJ43AAD	Electric Tachometer	General Electric
8DJ43AAE	Electric Tachometer	General Electric
8DJ43AAH	Electric Tachometer	General Electric
8DJ43AAK1	Electric Tachometer	General Electric
8DJ43AAK3	Electric Tachometer	General Electric
8DJ43AAK5	Electric Tachometer	General Electric
8DJ43AAM	Electric Tachometer	General Electric
8DJ43BAD	Electric Tachometer	General Electric
8DJ43BAE	Electric Tachometer	General Electric
8DJ43BAH	Electric Tachometer	General Electric
8DJ81AAA1	Tachometer Indicator	Ametek
8DJ81AAB1	Tachometer Indicator	Ametek
8DJ81AAC1	Tachometer Indicator	Ametek
8DJ81BAA1	Tachometer Indicator	Ametek
8DJ81BLB4	Tachometer Indicator	Ametek
8DJ81BLB4U	Tachometer Indicator	Ametek
8DJ81BLC4	Tachometer Indicator	Ametek
8DJ81BLC4	Tachometer Indicator	Ametek
8DJ81CAA1	Tachometer Indicator	Ametek
8DJ81CAA2	Tachometer Indicator	Ametek
8DJ81CAA4	Tachometer Indicator	General Electric
8DJ81CAB2	Tachometer Indicator	Ametek
8DJ81CAC1	Tachometer Indicator	Ametek
8DJ81CAC2	Tachometer Indicator	Ametek
8DJ81CAE1	Tachometer Indicator	Ametek
8DJ81CAE2	Tachometer Indicator	Ametek
8DJ81CAF1	Tachometer Indicator	Ametek
8DJ81CAF2	Tachometer Indicator	Ametek
8DJ81CAH1	Tachometer Indicator	Ametek
8DJ81CAH2	Tachometer Indicator	Ametek

8DJ81CAK1	Tachometer Indicator	Ametek
8DJ81CAK2	Tachometer Indicator	Ametek
8DJ81CAL1	Tachometer Indicator	Ametek
8DJ81CAM1	Tachometer Indicator	Ametek
8DJ81CAM2	Tachometer Indicator	Ametek
8DJ81CAN1	Tachometer Indicator	Ametek
8DJ81CAN2	Tachometer Indicator	Ametek
8DJ81CAN4	TachometerIndicator	General Electric
8DJ81CAS2	Tachometer Indicator	Ametek
8DJ81CAX2	Tachometer Indicator	Ametek
8DJ81CAY2	Tachometer Indicator	Ametek
8DJ81CAZ2	Tachometer Indicator	Ametek
8DJ81CBA2	Tachometer Indicator	Ametek
8DJ81CBB2	Tachometer Indicator	Ametek
8DJ81CBD4	TachometerIndicator	General Electric
8DJ81CBK2	Tachometer Indicator	Ametek
8DJ81CBX2	Tachometer Indicator	Ametek
8DJ81CCK2	Tachometer Indicator	Ametek
8DJ81CCL2	Tachometer Indicator	Ametek
8DJ81CCM2	Tachometer Indicator	Ametek
8DJ81CDC2	Tachometer Indicator	Ametek
8DJ81CDE2	Tachometer Indicator	Ametek
8DJ81CDH2	Tachometer Indicator	Ametek
8DJ81CDR4	TachometerIndicator	General Electric
8DJ81CDS4	TachometerIndicator	General Electric
8DJ81CDW4	TachometerIndicator	General Electric
8DJ81CDX4	TachometerIndicator	General Electric
8DJ81CDY2	Tachometer Indicator	Ametek
8DJ81CDZ4	TachometerIndicator	General Electric
8DJ81FAA1	Tachometer Indicator	Ametek
8DJ81FAA2	Tachometer Indicator	Ametek
8DJ81LAA1	Tachometer Indicator	Ametek
8DJ81LAA2	Tachometer Indicator	Ametek
8DJ81LAA4	Tachometer Indicator	Ametek
8DJ81LAA4U	Tachometer Indicator	Ametek
8DJ81LAB2	Tachometer Indicator	Ametek
8DJ81LAC1	Tachometer Indicator	Ametek
8DJ81LAC2	Tachometer Indicator	Ametek

8DJ81LAD1	Tachometer Indicator	Ametek
8DJ81LAD2	Tachometer Indicator	Ametek
8DJ81LAE1	Tachometer Indicator	Ametek
8DJ81LAE2	Tachometer Indicator	Ametek
8DJ81LAK1	Tachometer Indicator	Ametek
8DJ81LAK2	Tachometer Indicator	Ametek
8DJ81LAN2	Tachometer Indicator	Ametek
8DJ81LAT1	Tachometer Indicator	Ametek
8DJ81LAT2	Tachometer Indicator	Ametek
8DJ81LAV2	Tachometer Indicator	Ametek
8DJ81LAW1	Tachometer Indicator	Ametek
8DJ81LAW2	Tachometer Indicator	Ametek
8DJ81LAX2	Tachometer Indicator	Ametek
8DJ81LAY2	Tachometer Indicator	Ametek
8DJ81LAZ2	Tachometer Indicator	Ametek
8DJ81LBC2	Tachometer Indicator	Ametek
8DJ81LBD2	Tachometer Indicator	Ametek
8DJ81LBE2	Tachometer Indicator	Ametek
8DJ81LBF2	Tachometer Indicator	Ametek
8DJ81LBH2	Tachometer Indicator	Ametek
8DJ81LBK2	Tachometer Indicator	Ametek
8DJ81LBL2	Tachometer Indicator	Ametek
8DJ81LBS2	Tachometer Indicator	Ametek
8DJ81LBT2	Tachometer Indicator	Ametek
8DJ81LBX2	Tachometer Indicator	Ametek
8DJ81LCB2	Tachometer Indicator	Ametek
8DJ81LCD2	Tachometer Indicator	Ametek
8DJ81LCF2	Tachometer Indicator	Ametek
8DJ81LCK2	Tachometer Indicator	Ametek
8DJ81LCP4	Tachometer Indicator	Ametek
8DJ81LCP4U	Tachometer Indicator	Ametek
8DJ81LCR4	Tachometer Indicator	Ametek
8DJ81LCR4U	Tachometer Indicator	Ametek
8DJ81LCT4	Tachometer Indicator	Ametek
8DJ81LCT4U	Tachometer Indicator	Ametek
8DJ81LSC4	Tachometer Indicator	Ametek
8DJ81LSC4U	Tachometer Indicator	Ametek
8DJ81LVA4	Tachometer Indicator	Ametek

8DJ81LVA4U	Tachometer Indicator	Ametek
8DJ81LVB4	Tachometer Indicator	Ametek
8DJ81LVB4U	Tachometer Indicator	Ametek
8DJ81LVF4	Tachometer Indicator	Ametek
8DJ81LVF4U	Tachometer Indicator	Ametek
8DJ81LVG4	Tachometer Indicator	Ametek
8DJ81LVG4U	Tachometer Indicator	Ametek
8DJ81LVL4	Tachometer Indicator	Ametek
8DJ81LVL4U	Tachometer Indicator	Ametek
8DJ81LWA1	Tachometer Indicator	Ametek
8DJ81LWA2	Tachometer Indicator	Ametek
8DJ81LWA4	Tachometer Indicator	Ametek
8DJ81LWA4U	Tachometer Indicator	Ametek
8DJ81LWB2	Tachometer Indicator	Ametek
8DJ81LWC2	Tachometer Indicator	Ametek
8DJ81LWC4	Tachometer Indicator	Ametek
8DJ81LWC4U	Tachometer Indicator	Ametek
8DJ81LWH2	Tachometer Indicator	Ametek
8DJ81LWM2	Tachometer Indicator	Ametek
8DJ81LWR2	Tachometer Indicator	Ametek
8DJ81LWR4	Tachometer Indicator	Ametek
8DJ81LWR4U	Tachometer Indicator	Ametek
8DJ81LWS2	Tachometer Indicator	Ametek
8DJ81LWS4	Tachometer Indicator	Ametek
8DJ81LWS4U	Tachometer Indicator	Ametek
8DJ81LWT2	Tachometer Indicator	Ametek
8DJ81LWT4	Tachometer Indicator	Ametek
8DJ81LWT4U	Tachometer Indicator	Ametek
8DJ81LWV2	Tachometer Indicator	Ametek
8DJ81LWY2	Tachometer Indicator	Ametek
8DJ81LWY4	Tachometer Indicator	Ametek
8DJ81LWY4U	Tachometer Indicator	Ametek
8DJ81LWZ2	Tachometer Indicator	Ametek
8DJ81LWZ4	Tachometer Indicator	Ametek
8DJ81LWZ4U	Tachometer Indicator	Ametek
8DJ81LXC2	Tachometer Indicator	Ametek
8DJ81LXD2	Tachometer Indicator	Ametek
8DJ81LXE2	Tachometer Indicator	Ametek

8DJ81LXE2	Tachometer Indicator	Ametek
8DJ81LXF4	Tachometer Indicator	Ametek
8DJ81LXF4U	Tachometer Indicator	Ametek
8DJ81LXG2	Tachometer Indicator	Ametek
8DJ81LXG4	Tachometer Indicator	Ametek
8DJ81LXG4U	Tachometer Indicator	Ametek
8DJ81LXH2	Tachometer Indicator	Ametek
8DJ81LXH4	Tachometer Indicator	Ametek
8DJ81LXH4U	Tachometer Indicator	Ametek
8DJ81LXK2	Tachometer Indicator	Ametek
8DJ81LXK4	Tachometer Indicator	Ametek
8DJ81LXK4U	Tachometer Indicator	Ametek
8DJ81LXL2	Tachometer Indicator	Ametek
8DJ81LXM2	Tachometer Indicator	Ametek
8DJ81LXN2	Tachometer Indicator	Ametek
8DJ81LXP2	Tachometer Indicator	Ametek
8DJ81LXT4	Tachometer Indicator	Ametek
8DJ81LXT4U	Tachometer Indicator	Ametek
8DJ81LXV2	Tachometer Indicator	Ametek
8DJ81LXW2	Tachometer Indicator	Ametek
8DJ81LXY2	Tachometer Indicator	Ametek
8DJ81LXZ2	Tachometer Indicator	Ametek
8DJ81LYA2	Tachometer Indicator	Ametek
8DJ81LYB2	Tachometer Indicator	Ametek
8DJ81LYC2	Tachometer Indicator	Ametek
8DJ81LYP2	Tachometer Indicator	Ametek
8DJ81LYP4	Tachometer Indicator	Ametek
8DJ81LYP4U	Tachometer Indicator	Ametek
8DJ81LYT2	Tachometer Indicator	Ametek
8DJ81LYT4	Tachometer Indicator	Ametek
8DJ81LYT4U	Tachometer Indicator	Ametek
8DJ81LYV2	Tachometer Indicator	Ametek
8DJ81LYV4	Tachometer Indicator	Ametek
8DJ81LYV4U	Tachometer Indicator	Ametek
8DJ81LYW2	Tachometer Indicator	Ametek
8DJ81LYX2	Tachometer Indicator	Ametek
8DJ81LYX4	Tachometer Indicator	Ametek
8DJ81LYX4U	Tachometer Indicator	Ametek

8DJ81LYZ2	Tachometer Indicator	Ametek
8DJ81LZB2	Tachometer Indicator	Ametek
8DJ81LZC2	Tachometer Indicator	Ametek
8DJ81LZC4	Tachometer Indicator	Ametek
8DJ81LZC4U	Tachometer Indicator	Ametek
8DJ81LZE2	Tachometer Indicator	Ametek
8DJ81LZE4	Tachometer Indicator	Ametek
8DJ81LZE4U	Tachometer Indicator	Ametek
8DJ81LZF2	Tachometer Indicator	Ametek
8DJ81LZF4	Tachometer Indicator	Ametek
8DJ81LZF4U	Tachometer Indicator	Ametek
8DJ81WAG2	Tachometer Indicator	Ametek
8DJ81WAG4	Tachometer Indicator	Ametek
8DJ81WAG4U	Tachometer Indicator	Ametek
8DJ81WAL4	Tachometer Indicator	Ametek
8DJ81WAL4U	Tachometer Indicator	Ametek
8DJ81WAP4	Tachometer Indicator	Ametek
8DJ81WAP4	Tachometer Indicator	Ametek
8DJ81WAP4U	Tachometer Indicator	Ametek
8DJ81WAP4U	Tachometer Indicator	Ametek
8DJ81WAP4U	Tachometer Indicator	Ametek
8DJ81WAY4	Tachometer Indicator	Ametek
8DJ81WAY4U	Tachometer Indicator	Ametek
8DJ81WBA4	Tachometer Indicator	Ametek
8DJ81WBA4U	Tachometer Indicator	Ametek
8DJ81WBB4	Tachometer Indicator	Ametek
8DJ81WBB4U	Tachometer Indicator	Ametek
8DJ81WBC4	Tachometer Indicator	Ametek
8DJ81WBC4U	Tachometer Indicator	Ametek
8DJ81WBD4	Tachometer Indicator	Ametek
8DJ81WBD4U	Tachometer Indicator	Ametek
8DJ81WBF4	Tachometer Indicator	Ametek
8DJ81WBF4U	Tachometer Indicator	Ametek
8DJ81WBG4	Tachometer Indicator	Ametek
8DJ81WBG4U	Tachometer Indicator	Ametek
8DJ81WBL4	Tachometer Indicator	Ametek
8DJ81WBL4U	Tachometer Indicator	Ametek
8DJ81WBM4	Tachometer Indicator	Ametek
8DJ81WBM4U	Tachometer Indicator	Ametek

8DJ81WBS4	Tachometer Indicator	Ametek
8DJ81WBS4U	Tachometer Indicator	Ametek
8DJ81WBT4	Tachometer Indicator	Ametek
8DJ81WBT4U	Tachometer Indicator	Ametek
8DJ81WCF4	Tachometer Indicator	Ametek
8DJ81WCF4U	Tachometer Indicator	Ametek
8DJ81WCG4	Tachometer Indicator	Ametek
8DJ81WCG4U	Tachometer Indicator	Ametek
8DJ81WCR4	Tachometer Indicator	Ametek
8DJ81WCR4U	Tachometer Indicator	Ametek
8DJ81WCS4	Tachometer Indicator	Ametek
8DJ81WCS4U	Tachometer Indicator	Ametek
8DJ81WCT4	Tachometer Indicator	Ametek
8DJ81WCT4U	Tachometer Indicator	Ametek
8DJ81WCW4	Tachometer Indicator	Ametek
8DJ81WCW4U	Tachometer Indicator	Ametek
8DJ81WCX4	Tachometer Indicator	Ametek
8DJ81WCX4U	Tachometer Indicator	Ametek
8DJ81WDK4	Tachometer Indicator	Ametek
8DJ81WDK4U	Tachometer Indicator	Ametek
8DJ81WDL4	Tachometer Indicator	Ametek
8DJ81WDL4U	Tachometer Indicator	Ametek
8DJ89CAA1	Tachometer Indicator	General Electric
8DJ89CAA2	Tachometer Indicator	General Electric
8DJ89CAB1	Tachometer Indicator	General Electric
8DJ89CAB2	Tachometer Indicator	General Electric
8DJ89CAF1	Tachometer Indicator	General Electric
8DJ89CAF2	Tachometer Indicator	General Electric
8DJ89CAH1	Tachometer Indicator	General Electric
8DJ89CAH2	Tachometer Indicator	General Electric
8DJ89CAK1	Tachometer Indicator	General Electric
8DJ89CAK2	Tachometer Indicator	General Electric
8DJ89CAL1	Tachometer Indicator	General Electric
8DJ89CAL2	Tachometer Indicator	General Electric
8DJ89CAM1	Tachometer Indicator	General Electric
8DJ89CAM2	Tachometer Indicator	General Electric
8DJ89CAN1	Tachometer Indicator	General Electric
8DJ89CAN2	Tachometer Indicator	General Electric

8DJ89CAS1	Tachometer Indicator	General Electric
8DJ89CAS2	Tachometer Indicator	General Electric
8DJ89CAT1	Tachometer Indicator	General Electric
8DJ89CAT2	Tachometer Indicator	General Electric
8DJ89CAV1	Tachometer Indicator	General Electric
8DJ89CAW1	Tachometer Indicator	General Electric
8DJ89CAW2	Tachometer Indicator	General Electric
8DJ89CAX1	Tachometer Indicator	General Electric
8DJ89CAX2	Tachometer Indicator	General Electric
8DJ89CAY1	Tachometer Indicator	General Electric
8DJ89CAY2	Tachometer Indicator	General Electric
8DJ89CAZ1	Tachometer Indicator	General Electric
8DJ89CAZ2	Tachometer Indicator	General Electric
8DW53AAC231	Ammeter	General Electric
8DW53ACB230	Ammeter	General Electric
8DW53ACC227	Ammeter	General Electric
8DW53VBA207	Voltmeter	General Electric
8DW53VBA211	Voltmeter	General Electric
8GR1519	Overpressure Indicator	Custom Control
8TJ39AAA2	Position Transmitter	Sensors
8TJ39AAB2	Position Transmitter	General Electric
90G236	Gage Pressure Switch	General Electric
94P32	Gage Pressure Switch	Custom Control
9A-1036-2	Liquid Oxygen Quantity Indicator	Sensors
9A-1040	Liquid Oxygen Quantity Indicator	Penn Airborne
9A-225	Liquid Oxygen Quantity Indicator	Penn Airborne
9A-360	Liquid Oxygen Quantity Indicator	Penn Airborne
9A-360HEA	Liquid Oxygen Quantity Indicator	Penn Airborne
9A-4HEA	Liquid Oxygen Quantity Indicator	Penn Airborne
AS5945-2		
AW2017AD01		Ametek
AW-2-17-A	Hydraulic Pressure Gage	U.S. Gauge
B118-124		
B118-126		
B118-143		

B118-143W  
B118-143XW  
B118-144  
B118-312  
B118-312W  
B118-312XW  
B118-313  
B118-313W  
B118-313XW  
B118-314  
B118-314W  
B118-314XW  
B118-315  
B118-315W  
B118-315XW  
B118-316  
B118-316W  
B118-316XW  
B118-317  
B118-324  
B118-324W  
B118-324XW  
B118-336  
B118-337  
B118-338  
B118-339  
B118-340  
B118-341  
B118-342  
B118-356  
B118-357  
B118-58  
B118-59  
B118-59W  
B118-59XW  
B118-60  
B118-60W  
B118-60XW

Fuel Quantity Indicator

Simmonds

B118-61  
B118-61W  
B118-61XW  
B118-62  
B118-62W  
B118-62XW  
B118-63  
B118-64  
B118-65  
B118-66  
B118-67  
B118-95  
B118-95W  
B118-95XW  
B118-97

CDIA

DSF929

E37500

EA100AN17

EA100AN53

EA100AN70

EA100AN93

EA100ANH

EA100ANH126

EA100ANH133H

EA100ANH144

EA100ANH94

EA100ANH97

EA100ANH98

EA1015A-1957

EA102AN116

EA102AN44

EA102AN65

EA1065AW-1827

EA1065AW-2315

EA1093A-3544

EA1093A-3679

EA1093AW3679

Aircraft Clocks

Fuel Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Quantity Indicator

Tank Unit, Fuel Quantity

Quantity Indicator

Quantity Indicator

Quantity Indicator

Oil Quantity Tank Unit

Liquid Quantity Transmitter

Liquid Quantity Transmitter

Liquid Quantity Transmitter

Waltham

Consolidated Airborne

Elgin

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Liquidometer

Simmonds/BFGoodrich

Simmonds/BFGoodrich

Simmonds/BFGoodrich

EA124AN110	Quantity Indicator	Liquidometer
EA124AN115	Quantity Indicator	Liquidometer
EA148AN46	Quantity Indicator	Liquidometer
EA148AN47	Quantity Indicator	Liquidometer
EA148AN51	Quantity Indicator	Liquidometer
EA148AN71	Quantity Indicator	Liquidometer
EA148ANH-70	Indicator, Hydraulic oil Quantity	Liquidometer
EA173E1	Position Transmitter	Liquidometer
EA173E2		
EA307AN-1	Position Indicator	Liquidometer
EA307AN-1	Position Indicators	Liquidometer
EA308-1	Position Indicator	Liquidometer
EA308-1		
EA308-10	Position Indicator	Liquidometer
EA308-10		
EA308-11	Position Indicator	Liquidometer
EA308-11		
EA308-2	Position Indicator	Liquidometer
EA308-2		
EA308-3	Position Indicator	Liquidometer
EA308-3		
EA573A-1	Position Transmitter	Liquidometer
EA573A-5	Position Transmitter	Liquidometer
EA573A-6	Position Transmitter	Liquidometer
EA573A-7	Position Transmitter	Liquidometer
EA753A-6A	Position Transmitter	Liquidometer
EA7573C-2A	Position Transmitter	Liquidometer
EA7722856	Fuel Quantity Tank Unit	Honeywell
EA7722857	Fuel Quantity Tank Unit	Honeywell
EA7722858	Fuel Quantity Tank Unit	Honeywell
EA7722859	Fuel Quantity Tank Unit	Honeywell
EA773C-1A	Position Transmitter	Liquidometer
EG116D1	Fuel Quantity Amplifier	Honeywell
F71-1A	Indicator, Wing Flap Position	United Control Corp.
FG120G10	Tank Unit	
FG120G11	Tank Unit	
FG120G3	Tank Unit	Honeywell
FG120G4	Tank Unit	Honeywell

FG120G5	Tank Unit	
FG120G8	Tank Unit	
FG120H10	Tank Unit	
FG120H11	Tank Unit	
FG120H12	Tank Unit	
FG120H14	Tank Unit	
FG120H15	Tank Unit	
FG120H16	Tank Unit	
FG120H6	Tank Unit	
FG120H7	Tank Unit	
FG120H8	Tank Unit	
FG120H9	Tank Unit	
FG120K1	Tank Unit	
FG120K2	Tank Unit	
FG120K3	Tank Unit	
FG120K4	Tank Unit	
FG120K5	Tank Unit	
FG120K6	Tank Unit	
FG120K7	Tank Unit	
FG120K8	Tank Unit	
FG120L1	Tank Unit	
FG120L10	Tank Unit	
FG120L11	Tank Unit	
FG120L12	Tank Unit	
FG120L2	Tank Unit	
FG120L3	Tank Unit	
FG120L4	Tank Unit	
FG120L5	Tank Unit	
FG120L6	Tank Unit	
FG120L7	Tank Unit	
FG120L8	Tank Unit	
FG120L9	Tank Unit	
FG200A13	Fuel Quantity Tank Unit	Honeywell
FG200A57		
FG200A65		
FG200A68		
FG200A72		
FG200A73		

FG200A75		
FG200A76		
FG200A77		
FG200A78		
FG200A82		
FG201A20		
FG201A25		
FG210A13		
FG220A100	Fuel Quantity Tank Unit	Honeywell
FG220A101	Fuel Quantity Tank Unit	Honeywell
FG220A102	Fuel Quantity Tank Unit	Honeywell
FG220A103	Fuel Quantity Tank Unit	Honeywell
FG220A104	Fuel Quantity Tank Unit	Honeywell
FG220A105	Fuel Quantity Tank Unit	Honeywell
FG220A106	Fuel Quantity Tank Unit	Honeywell
FG220A107	Fuel Quantity Tank Unit	Honeywell
FG220A108	Fuel Quantity Tank Unit	Honeywell
FG220A109	Fuel Quantity Tank Unit	Honeywell
FG220A110	Fuel Quantity Tank Unit	Honeywell
FG220A111	Fuel Quantity Tank Unit	Honeywell
FG220A112	Fuel Quantity Tank Unit	Honeywell
FG220A113	Fuel Quantity Tank Unit	Honeywell
FG220A114	Fuel Quantity Tank Unit	Honeywell
FG220A115	Fuel Quantity Tank Unit	Honeywell
FG220A155	Fuel Quantity Tank Unit	Honeywell
FG220A156	Fuel Quantity Tank Unit	Honeywell
FG220A175	Fuel Quantity Tank Unit	Honeywell
FG220A176	Fuel Quantity Tank Unit	Honeywell
FG220A177	Fuel Quantity Tank Unit	Honeywell
FG220A178	Fuel Quantity Tank Unit	Honeywell
FG220A179	Fuel Quantity Tank Unit	Honeywell
FG220A192	Fuel Quantity Tank Unit	Honeywell
FG220A193	Fuel Quantity Tank Unit	Honeywell
FG220A194	Fuel Quantity Tank Unit	Honeywell
FG220A195	Fuel Quantity Tank Unit	Honeywell
FG220A196	Fuel Quantity Tank Unit	Honeywell
FG220A197	Fuel Quantity Tank Unit	Honeywell
FG220A198	Fuel Quantity Tank Unit	Honeywell

FG220A199	Fuel Quantity Tank Unit	Honeywell
FG220A200	Fuel Quantity Tank Unit	Honeywell
FG220A201	Fuel Quantity Tank Unit	Honeywell
FG220A202	Fuel Quantity Tank Unit	Honeywell
FG220A203	Fuel Quantity Tank Unit	Honeywell
FG220A204	Fuel Quantity Tank Unit	Honeywell
FG220A205	Fuel Quantity Tank Unit	Honeywell
FG220A206	Fuel Quantity Tank Unit	Honeywell
FG220A207	Fuel Quantity Tank Unit	Honeywell
FG220A208	Fuel Quantity Tank Unit	Honeywell
FG220A209	Fuel Quantity Tank Unit	Honeywell
FG220A210	Fuel Quantity Tank Unit	Honeywell
FG220A211	Fuel Quantity Tank Unit	Honeywell
FG220A212	Fuel Quantity Tank Unit	Honeywell
FG220A213	Fuel Quantity Tank Unit	Honeywell
FG220A214	Fuel Quantity Tank Unit	Honeywell
FG220A215	Fuel Quantity Tank Unit	Honeywell
FG220A216	Fuel Quantity Tank Unit	Honeywell
FG220A237	Fuel Quantity Tank Unit	Honeywell
FG220A238	Fuel Quantity Tank Unit	Honeywell
FG220A239	Fuel Quantity Tank Unit	Honeywell
FG220A240	Fuel Quantity Tank Unit	Honeywell
FG220A241	Fuel Quantity Tank Unit	Honeywell
FG220A242	Fuel Quantity Tank Unit	Honeywell
FG220A243	Fuel Quantity Tank Unit	Honeywell
FG220A244	Fuel Quantity Tank Unit	Honeywell
FG220A245	Fuel Quantity Tank Unit	Honeywell
FG220A246	Fuel Quantity Tank Unit	Honeywell
FG220A247	Fuel Quantity Tank Unit	Honeywell
FG220A248	Fuel Quantity Tank Unit	Honeywell
FG220A249	Fuel Quantity Tank Unit	Honeywell
FG220A250	Fuel Quantity Tank Unit	Honeywell
FG220A251	Fuel Quantity Tank Unit	Honeywell
FG220A252	Fuel Quantity Tank Unit	Honeywell
FG220A253	Fuel Quantity Tank Unit	Honeywell
FG220A254	Fuel Quantity Tank Unit	Honeywell
FG220A255	Fuel Quantity Tank Unit	Honeywell
FG220A256	Fuel Quantity Tank Unit	Honeywell

FG220A257	Fuel Quantity Tank Unit	Honeywell
FG220A258	Fuel Quantity Tank Unit	Honeywell
FG220A259	Fuel Quantity Tank Unit	Honeywell
FG220A260	Fuel Quantity Tank Unit	Honeywell
FG220A261	Fuel Quantity Tank Unit	Honeywell
FG220A60	Fuel Quantity Tank Unit	Honeywell
FG220A61	Fuel Quantity Tank Unit	Honeywell
FG220A62	Fuel Quantity Tank Unit	Honeywell
FG220A63	Fuel Quantity Tank Unit	Honeywell
FG220A64	Fuel Quantity Tank Unit	Honeywell
FG220A65	Fuel Quantity Tank Unit	Honeywell
FG220A66	Fuel Quantity Tank Unit	Honeywell
FG220A67	Fuel Quantity Tank Unit	Honeywell
FG220A68	Fuel Quantity Tank Unit	Honeywell
FG220A75	Fuel Quantity Tank Unit	Honeywell
FG220A76	Fuel Quantity Tank Unit	Honeywell
FG220A83	Fuel Quantity Tank Unit	Honeywell
FG220A95	Fuel Quantity Tank Unit	Honeywell
FG220A96	Fuel Quantity Tank Unit	Honeywell
FG220A97	Fuel Quantity Tank Unit	Honeywell
FG220A98	Fuel Quantity Tank Unit	Honeywell
FG220A99	Fuel Quantity Tank Unit	Honeywell
FG225A1		
FG225A10		
FG225A3		
FG225A7		
FG225A8		
FG225A9		
FG226A1		
FG226A3		
FG226A5		
FG240A1		
FG240A5		
FG250A42		
FG250A43		
FG250A44		
FG250A53		
FG250A6	Fuel Quantity Tank Unit	Honeywell

FG250A7		
FG250A8		
FG430A237	Fuel Quantity Tank Unit	Honeywell
FG430A238	Fuel Quantity Tank Unit	Honeywell
FG430A239	Fuel Quantity Tank Unit	Honeywell
FG430A240	Fuel Quantity Tank Unit	Honeywell
FG430A241	Fuel Quantity Tank Unit	Honeywell
FG430A242	Fuel Quantity Tank Unit	Honeywell
FG430A243	Fuel Quantity Tank Unit	Honeywell
FG430A244	Fuel Quantity Tank Unit	Honeywell
FG430A245	Fuel Quantity Tank Unit	Honeywell
FG430A246	Fuel Quantity Tank Unit	Honeywell
FG430A247	Fuel Quantity Tank Unit	Honeywell
FG430A248	Fuel Quantity Tank Unit	Honeywell
FG430A249	Fuel Quantity Tank Unit	Honeywell
FG430A250	Fuel Quantity Tank Unit	Honeywell
FG430A251	Fuel Quantity Tank Unit	Honeywell
FG430A252	Fuel Quantity Tank Unit	Honeywell
FG430A253	Fuel Quantity Tank Unit	Honeywell
FG430A254	Fuel Quantity Tank Unit	Honeywell
FG430A255	Fuel Quantity Tank Unit	Honeywell
FG430A256	Fuel Quantity Tank Unit	Honeywell
FG430A257	Fuel Quantity Tank Unit	Honeywell
FG430A258	Fuel Quantity Tank Unit	Honeywell
FG430A259	Fuel Quantity Tank Unit	Honeywell
FG450A51		
FG450A53		
H37500		Hamilton
ID-1805/AJN-18		
JG130A68	Fuel Quantity Indicator	Honeywell
JG131A35	Fuel Quantity Indicator	Honeywell
JG131A36	Fuel Quantity Indicator	Honeywell
JG131A37	Fuel Quantity Indicator	Honeywell
JG131A38	Fuel Quantity Indicator	Honeywell
JG131A40	Fuel Quantity Indicator	Honeywell
JG131A41	Fuel Quantity Indicator	Honeywell
JG131A42	Fuel Quantity Indicator	Honeywell
JG131A43	Fuel Quantity Indicator	Honeywell

JG131A45	Fuel Quantity Indicator	Honeywell
JG131A51	Fuel Quantity Indicator	Honeywell
JG131A53	Fuel Quantity Indicator	Honeywell
JG131A54	Fuel Quantity Indicator	Honeywell
JG131A55	Fuel Quantity Indicator	Honeywell
JG131A56	Fuel Quantity Indicator	Honeywell
JG131A57	Fuel Quantity Indicator	Honeywell
JG131A58	Fuel Quantity Indicator	Honeywell
JG131A59	Fuel Quantity Indicator	Honeywell
JG131A60	Fuel Quantity Indicator	Honeywell
JG131A61	Fuel Quantity Indicator	Honeywell
JG131A67	Fuel Quantity Indicator	Honeywell
JG131A68	Fuel Quantity Indicator	Honeywell
JG131A69	Fuel Quantity Indicator	Honeywell
JG131A70	Fuel Quantity Indicator	Honeywell
JG131A71	Fuel Quantity Indicator	Honeywell
JG131A73	Fuel Quantity Indicator	Honeywell
JG131A74	Fuel Quantity Indicator	Honeywell
JG131A75	Fuel Quantity Indicator	Honeywell
JG131A76	Fuel Quantity Indicator	Honeywell
JG131A77	Fuel Quantity Indicator	Honeywell
JG131A79	Fuel Quantity Indicator	Honeywell
JG131A80	Fuel Quantity Indicator	Honeywell
JG131A83	Fuel Quantity Indicator	Honeywell
JG132B5	Fuel Quantity Indicator	Honeywell
JG132B6		
JG132B8		
JG151A-1	Pressure Ratio Indicator	Honeywell
JG298B1	Pressure Ratio Indicator	Honeywell
JG298H1	Pressure Ratio Indicator	Honeywell
JG298H2		
JG3B10	Fuel Quantity Indicator	Honeywell
JG3B11	Fuel Quantity Indicator	Honeywell
JG3B12	Fuel Quantity Indicator	Honeywell
JG3B9	Fuel Quantity Indicator	Honeywell
JG402A2	Fuel Quantity Indicator	Honeywell
JG402A3	Fuel Quantity Indicator	Honeywell
JG402A32	Fuel Quantity Indicator	Honeywell

JG402A4	Fuel Quantity Indicator	Honeywell
JG402A52	Fuel Quantity Indicator	Honeywell
JG402A53	Fuel Quantity Indicator	Honeywell
JG402A54	Fuel Quantity Indicator	Honeywell
JG402A55	Fuel Quantity Indicator	Honeywell
JG403A30	Fuel Quantity Indicator	Honeywell
JG403B1	Fuel Quantity Indicator	Honeywell
JG403B10	Fuel Quantity Indicator	Honeywell
JG403B11	Fuel Quantity Indicator	Honeywell
JG403B12	Fuel Quantity Indicator	Honeywell
JG403B13	Fuel Quantity Indicator	Honeywell
JG403B14	Fuel Quantity Indicator	Honeywell
JG403B15	Fuel Quantity Indicator	Honeywell
JG403B2	Fuel Quantity Indicator	Honeywell
JG403B3	Fuel Quantity Indicator	Honeywell
JG403B4	Fuel Quantity Indicator	Honeywell
JG403B5	Fuel Quantity Indicator	Honeywell
JG403B6	Fuel Quantity Indicator	Honeywell
JG403B7	Fuel Quantity Indicator	Honeywell
JG403B9	Fuel Quantity Indicator	Honeywell
JG412A1	Fuel Quantity Indicator	Honeywell
JG412A10		
JG412A11		
JG412A2	Fuel Quantity Indicator	Honeywell
JG412A3		
JG412A4		
JG412A52		
JG412A53		
JG412A54		
JG412A55		
JG412A56		
JG42B1	Pressure Ratio Indicator	Honeywell
JG42B4		
JG4B1	Fuel Quantity Indicator	Honeywell
JG4B9	Fuel Quantity Indicator	Honeywell
JG603C2	Fuel Quantity Indicator	Honeywell
JG603C3	Fuel Quantity Indicator	Honeywell
JG603C4	Fuel Quantity Indicator	Honeywell

JG603C42	Fuel Quantity Indicator	Honeywell
JG603C43	Fuel Quantity Indicator	Honeywell
JG603C44	Fuel Quantity Indicator	Honeywell
JG603C51	Fuel Quantity Indicator	Honeywell
JG603C52	Fuel Quantity Indicator	Honeywell
JG603C67	Fuel Quantity Indicator	Honeywell
JG603C70	Fuel Quantity Indicator	Honeywell
JG603C73	Fuel Quantity Indicator	Honeywell
JG603C78	Fuel Quantity Indicator	Honeywell
JG603C80	Fuel Quantity Indicator	Honeywell
JG603C81	Fuel Quantity Indicator	Honeywell
JG7020A10	Fuel or Oil Quantity Indicator	Honeywell
JG7020A11	Fuel or Oil Quantity Indicator	Honeywell
JG7020A12	Fuel or Oil Quantity Indicator	Honeywell
JG7020A13	Fuel or Oil Quantity Indicator	Honeywell
JG7020A18	Fuel or Oil Quantity Indicator	Honeywell
JG7020A19	Fuel or Oil Quantity Indicator	Honeywell
JG7020A2	Fuel or Oil Quantity Indicator	Honeywell
JG7020A20	Fuel or Oil Quantity Indicator	Honeywell
JG7020A21	Fuel or Oil Quantity Indicator	Honeywell
JG7020A22	Fuel or Oil Quantity Indicator	Honeywell
JG7020A23	Fuel or Oil Quantity Indicator	Honeywell
JG7020A24	Fuel or Oil Quantity Indicator	Honeywell
JG7020A25	Fuel or Oil Quantity Indicator	Honeywell
JG7020A26	Fuel or Oil Quantity Indicator	Honeywell
JG7020A27	Fuel or Oil Quantity Indicator	Honeywell
JG7020A28	Fuel or Oil Quantity Indicator	Honeywell
JG7020A29	Fuel or Oil Quantity Indicator	Honeywell
JG7020A3	Fuel or Oil Quantity Indicator	Honeywell
JG7020A30	Fuel or Oil Quantity Indicator	Honeywell
JG7020A31	Fuel or Oil Quantity Indicator	Honeywell
JG7020A32	Fuel or Oil Quantity Indicator	Honeywell
JG7020A34	Fuel or Oil Quantity Indicator	Honeywell
JG7020A35	Fuel or Oil Quantity Indicator	Honeywell
JG7020A36	Fuel or Oil Quantity Indicator	Honeywell
JG7020A38	Fuel or Oil Quantity Indicator	Honeywell
JG7020A39	Fuel or Oil Quantity Indicator	Honeywell
JG7020A4	Fuel or Oil Quantity Indicator	Honeywell

JG7020A40	Fuel or Oil Quantity Indicator	Honeywell
JG7020A42	Fuel or Oil Quantity Indicator	Honeywell
JG7020A43	Fuel or Oil Quantity Indicator	Honeywell
JG7020A47	Fuel or Oil Quantity Indicator	Honeywell
JG7020A48	Fuel or Oil Quantity Indicator	Honeywell
JG7020A49	Fuel or Oil Quantity Indicator	Honeywell
JG7020A5	Fuel or Oil Quantity Indicator	Honeywell
JG7020A50	Fuel or Oil Quantity Indicator	Honeywell
JG7020A51	Fuel or Oil Quantity Indicator	Honeywell
JG7020A52	Fuel or Oil Quantity Indicator	Honeywell
JG7020A53	Fuel or Oil Quantity Indicator	Honeywell
JG7020A54	Fuel or Oil Quantity Indicator	Honeywell
JG7020A55	Fuel or Oil Quantity Indicator	Honeywell
JG7020A57	Fuel or Oil Quantity Indicator	Honeywell
JG7020A58	Fuel or Oil Quantity Indicator	Honeywell
JG7020A6	Fuel or Oil Quantity Indicator	Honeywell
JG7020A60	Fuel or Oil Quantity Indicator	Honeywell
JG7020A61	Fuel or Oil Quantity Indicator	Honeywell
JG7020A62	Fuel or Oil Quantity Indicator	Honeywell
JG7020A63	Fuel or Oil Quantity Indicator	Honeywell
JG7020A65	Fuel or Oil Quantity Indicator	Honeywell
JG7020A66	Fuel or Oil Quantity Indicator	Honeywell
JG7020A67	Fuel or Oil Quantity Indicator	Honeywell
JG7020A68	Fuel or Oil Quantity Indicator	Honeywell
JG7020A7	Fuel or Oil Quantity Indicator	Honeywell
JG7020A70	Fuel or Oil Quantity Indicator	Honeywell
JG7020A71	Fuel or Oil Quantity Indicator	Honeywell
JG7020A72	Fuel or Oil Quantity Indicator	Honeywell
JG7020A73	Fuel or Oil Quantity Indicator	Honeywell
JG7020A74	Fuel or Oil Quantity Indicator	Honeywell
JG7020A77	Fuel or Oil Quantity Indicator	Honeywell
JG7020C1	Fuel or Oil Quantity Indicator	Honeywell
JG7020C2	Fuel or Oil Quantity Indicator	Honeywell
JG7020C3	Fuel or Oil Quantity Indicator	Honeywell
JG7020C9	Fuel or Oil Quantity Indicator	Honeywell
JG7021A16	Fuel or Oil Quantity Indicator	Honeywell
JG7021A17	Fuel or Oil Quantity Indicator	Honeywell
JG7021A18	Fuel or Oil Quantity Indicator	Honeywell

JG7021A19	Fuel or Oil Quantity Indicator	Honeywell
JG7021A2	Fuel or Oil Quantity Indicator	Honeywell
JG7021A20	Fuel or Oil Quantity Indicator	Honeywell
JG7021A21	Fuel or Oil Quantity Indicator	Honeywell
JG7021A22	Fuel or Oil Quantity Indicator	Honeywell
JG7021A23	Fuel or Oil Quantity Indicator	Honeywell
JG7021A24	Fuel or Oil Quantity Indicator	Honeywell
JG7021A25	Fuel or Oil Quantity Indicator	Honeywell
JG7021A26	Fuel or Oil Quantity Indicator	Honeywell
JG7021A27	Fuel or Oil Quantity Indicator	Honeywell
JG7021A28	Fuel or Oil Quantity Indicator	Honeywell
JG7021A29	Fuel or Oil Quantity Indicator	Honeywell
JG7021A3	Fuel or Oil Quantity Indicator	Honeywell
JG7021A31	Fuel or Oil Quantity Indicator	Honeywell
JG7021A32	Fuel or Oil Quantity Indicator	Honeywell
JG7021A33	Fuel or Oil Quantity Indicator	Honeywell
JG7021A34	Fuel or Oil Quantity Indicator	Honeywell
JG7021A35	Fuel or Oil Quantity Indicator	Honeywell
JG7021A36	Fuel or Oil Quantity Indicator	Honeywell
JG7021A37	Fuel or Oil Quantity Indicator	Honeywell
JG7021A38	Fuel or Oil Quantity Indicator	Honeywell
JG7021A39	Fuel or Oil Quantity Indicator	Honeywell
JG7021A40	Fuel or Oil Quantity Indicator	Honeywell
JG7021A46	Fuel or Oil Quantity Indicator	Honeywell
JG7021A47	Fuel or Oil Quantity Indicator	Honeywell
JG7021A48	Fuel or Oil Quantity Indicator	Honeywell
JG7021A50	Fuel or Oil Quantity Indicator	Honeywell
JG7021A52	Fuel or Oil Quantity Indicator	Honeywell
JG7021A53	Fuel or Oil Quantity Indicator	Honeywell
JG7021A54	Fuel or Oil Quantity Indicator	Honeywell
JG7021A55	Fuel or Oil Quantity Indicator	Honeywell
JG7021A56	Fuel or Oil Quantity Indicator	Honeywell
JG7021A57	Fuel or Oil Quantity Indicator	Honeywell
JG7021A58	Fuel or Oil Quantity Indicator	Honeywell
JG7021A59	Fuel or Oil Quantity Indicator	Honeywell
JG7021A6	Fuel or Oil Quantity Indicator	Honeywell
JG7021A60	Fuel or Oil Quantity Indicator	Honeywell
JG7021A61	Fuel or Oil Quantity Indicator	Honeywell

JG7021A62	Fuel or Oil Quantity Indicator	Honeywell
JG7021A63	Fuel or Oil Quantity Indicator	Honeywell
JG7021A64	Fuel or Oil Quantity Indicator	Honeywell
JG7021A65	Fuel or Oil Quantity Indicator	Honeywell
JG7021A66	Fuel or Oil Quantity Indicator	Honeywell
JG7021A67	Fuel or Oil Quantity Indicator	Honeywell
JG7021A68	Fuel or Oil Quantity Indicator	Honeywell
JG7021A69	Fuel or Oil Quantity Indicator	Honeywell
JG7021A7	Fuel or Oil Quantity Indicator	Honeywell
JG7021A70	Fuel or Oil Quantity Indicator	Honeywell
JG7021A71	Fuel or Oil Quantity Indicator	Honeywell
JG7021A72	Fuel or Oil Quantity Indicator	Honeywell
JG7021A73	Fuel or Oil Quantity Indicator	Honeywell
JG7021A74	Fuel or Oil Quantity Indicator	Honeywell
JG7021A75	Fuel or Oil Quantity Indicator	Honeywell
JG7021A76	Fuel or Oil Quantity Indicator	Honeywell
JG7021A77	Fuel or Oil Quantity Indicator	Honeywell
JG7021A78	Fuel or Oil Quantity Indicator	Honeywell
JG7021A79	Fuel or Oil Quantity Indicator	Honeywell
JG7021A8	Fuel or Oil Quantity Indicator	Honeywell
JG7021A80	Fuel or Oil Quantity Indicator	Honeywell
JG7021A81	Fuel or Oil Quantity Indicator	Honeywell
JG7021A82	Fuel or Oil Quantity Indicator	Honeywell
JG7021A83	Fuel or Oil Quantity Indicator	Honeywell
JG7021A84	Fuel or Oil Quantity Indicator	Honeywell
JG7021A85	Fuel or Oil Quantity Indicator	Honeywell
JG7021A86	Fuel or Oil Quantity Indicator	Honeywell
JG7021A87	Fuel or Oil Quantity Indicator	Honeywell
JG7021A88	Fuel or Oil Quantity Indicator	Honeywell
JG7021A89	Fuel or Oil Quantity Indicator	Honeywell
JG7021A90	Fuel or Oil Quantity Indicator	Honeywell
JG7021A91	Fuel or Oil Quantity Indicator	Honeywell
JG7021A94	Fuel or Oil Quantity Indicator	Honeywell
JG7021A96	Fuel or Oil Quantity Indicator	Honeywell
JG7021C1	Fuel or Oil Quantity Indicator	Honeywell
JG7021C2	Fuel or Oil Quantity Indicator	Honeywell
JG7021C3	Fuel or Oil Quantity Indicator	Honeywell
JH5500	Directional Gyro Indicator	Jack and Heintz

LG14C12		
LG14C20	Pressure Ratio Transducer	Honeywell
MS28005-1		
MS28054-2	Tachometer Generator	Jack and Heinz
MS28130-4		(US Gauge Division)
RG10310	Radar Pressurizing Control	Strube, Inc.
RG50V4		
RG50Z2		
S332T004-2	Gage Pressure Switch	BCAC
S332T004-35	Gage Pressure Switch	BCAC
SA1-1-70000		Avionix Corp.
SLZ9065	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9066	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9067	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9068	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9155	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9211	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9239	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9270	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9415	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9416	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9603	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9620	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9635	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9638	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9669	Inertial-lead Vertical Speed Indicator	Teledyne Avionics

SLZ9669-2	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9706	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9851	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SLZ9851-1	Inertial-lead Vertical Speed Indicator	Teledyne Avionics
SR-3A	Synchro Style Pressure Indicator	U.S. Gauge
SR-3A		
SR-3C	Synchro Style Pressure Indicator	U.S. Gauge
SR-3C		
SR-4A	Synchro Style Pressure Indicator	U.S. Gauge
SR-4A	Synchro Pressure Indicator	US Gauge
SR-4B	Synchro Style Pressure Indicator	U.S. Gauge
SR-4B		
SR-5A	Synchro Style Pressure Indicator	U.S. Gauge
SR-5A		
SR-5B	Synchro Style Pressure Indicator	U.S. Gauge
SR-5B		
SR-7A	Synchro Style Pressure Indicator	U.S. Gauge
SR-7A		
SR-8B	Synchro Style Pressure Indicator	U.S. Gauge
SR-8B		
SR-9A	Synchro Style Pressure Indicator	U.S. Gauge
SR-9A		
SRDS-15A	Thrust, Pressure Ratio Indicator	U.S.Gauge
SRDS-15C	Pressure Ratio Indicator	US Gauge
SRDS-15C	Thrust, Pressure Ratio Indicator	U.S.Gauge
SRL-92G	Position Indicator	Ametek
SRL-92H	Pneumatic Pressure Indicator	
SRL-92P	Pneumatic Pressure Indicator	
ST-104A	Oil Pressure Transmitter	U.S. Gauge
ST-104A		
ST-104A	Oil Pressure Transmitter	US Gauge
ST-104A1		
ST-104A1		
ST-104D		
ST-104D		

ST-3A		
ST-3E		
ST-4B	Pressure Transmitter, Synchro Style	US Gauge
ST-4C		
ST-4D		
ST-4E		
ST-4H		
ST-4J		
ST-5E	Fuel Pressure Transmitter	US Gauge
ST-62A		
ST-63A	Pressure Transmitter	US Gauge
ST-6AD	Synchro Pressure Transmitter	Ametek, Inc.
ST-6B	Multipurpose Pressure Transmitter	US Gauge
ST-6C		
ST-9A		
T9844140	Flasher, Nav. Light	
TG255-001	Tachometer Generator	Advance Power Inc.
TG255-002	Tachometer Generator	Advance Power Inc.
TG255-003	Tachometer Generator	Advance Power Inc.
TG255-004	Tachometer Generator	Advance Power Inc.
TG255-005	Tachometer Generator	Advance Power Inc.
TG255-006	Tachometer Generator	Advance Power Inc.
TG255-007	Tachometer Generator	Advance Power Inc.
TG255-008	Tachometer Generator	Advance Power Inc.
Type TRU-80/A	Oil Pressure Transmitter	
	Tachometer Indicator	Ametek